

NB: if you would like to hire Council's microphones, request to do so when you book this hall. The microphones and key will then need to be collected from Council's Administration Building on the business day prior to your hire.

To book this hall, please go to Council's website ([www.kiama.nsw.gov.au](http://www.kiama.nsw.gov.au)) for further information and details relating to how to book, or call 02 4232 0444.

## Overview:

This audio system is well suited for community events, ranging from public meetings or presentations, through to use with light-medium band/performance applications.

It includes:


- Speakers mounted each side of stage, and mid-way down the room to provide even coverage throughout the hall
- A touchscreen located at the side of the stage with a customised user interface to provide simple control of the system
- Two handheld wireless microphones (*that need to be requested upon applying to hire the hall*)
- Inputs for two wired microphones located below the touch panel,
- A Bluetooth audio connection
- One 3.5mm Aux connection for mobile devices & laptops, located below the touch panel
- A stereo mixer input located below the touch panel, enabling bands to connect their own mixing equipment to the audio system.

## Startup options:

The touch screen adjacent to the stage will allow you to turn on the system. If the touch screen has not been used for a little while, the screen will be black – simply touch it to activate the panel.

Press the “Audio Power On” button, this will turn the system on.


The screen will then change to the Audio page.



## Audio:

On this Audio page you can:


- Adjust the volume of each input by sliding the fader up or down.
- Mute the input by pressing the mute button. The mute button will light up red if it is selected



Please note:

- Wireless 1 and 2 control the handheld wireless microphones
- The Mic 1 and Mic 2 faders control the two microphone inputs below the touchscreen for wired microphones
- The Aux volume control is for the 3.5mm auxiliary input socket on the plate below the touch panel

## Bluetooth:



If you press the “Pair” button underneath the Bluetooth fader, you will see this screen.

Press “Enable Pairing” to pair your phone to the system using your phones Bluetooth settings. The pairing options will stay active for 1 minute.

Otherwise press “Cancel” to return to the Audio page.

## Power:

If you press the “Power” button in the bottom left corner of the touch screen you will see this screen appear:

You can choose to shut down the audio system, or press cancel to return to the Audio page.

Shutting down the audio system will return to the startup page.

